







| | | |
|---------|--|---|
| 1259807 | ZF 0091 298 001 Gasket set gearbox dph |  |
| 1249150 | ZF 0501 310 614 Gasket valve |  |
| 1258789 | ZF 0501 312 738 Oil seal manual transmission |  |
| 1258986 | ZF 0501 314 060 Oil seal manual transmission |  |
| 1259825 | ZF 0501 314 587 Gasket gearbox |  |
| 1260827 | ZF 0501 315 106 Gasket |  |
| 1259794 | ZF 0501 316 778 washer |  |
| 1259836 | ZF 0501 317 536 Sealing ring |  |
| 1258206 | ZF 0501 321 065 Gasket gearbox metal |  |
| 1258208 | ZF 0501 322 828 Gasket gearbox metal |  |

| | | |
|---------|---|---|
| 1258209 | ZF 0501 322 829 Gasket gearbox metal |  |
| 1258211 | ZF 0501 324 626 Gasket gearbox dph |  |
| 1260925 | ZF 0634 300 020 Oil seal manual transmission |  |
| 1247958 | ZF 0634 300 185 oil seal |  |
| 1247516 | ZF 0634 300 302 Oil seal manual transmission |  |
| 1254804 | ZF 0634 300 412 Oil seal differential |  |
| 1253913 | ZF 0634 300 466 Oil seal crankshaft |  |
| 1258351 | ZF 0634 300 521 Oil seal differential |  |
| 1247959 | ZF 0634 300 540 oil seal |  |
| 1252537 | ZF 0634 300 712 Oil seal manual transmission |  |

| | | |
|---------|--|--|
| 1250251 | ZF 0634 302 121 oil seal |  |
| 1253445 | ZF 0634 302 143 oil seal |  |
| 1254055 | ZF 0634 309 092 Oil seal wheel hub |  |
| 1250250 | ZF 0634 309 104 oil seal |  |
| 1254096 | ZF 0634 309 106 Oil seal differential |  |
| 1254054 | ZF 0634 310 675 Oil seal differential | |
| 1257350 | ZF 0634 801 050 Washer oil outlet | |
| 1257351 | ZF 0634 801 062 Washer oil outlet | |
| 1257352 | ZF 0634 801 063 Washer oil outlet | |
| 1257349 | ZF 0634 801 205 Washer oil outlet | |

1259715 ZF 0634 801 217
Washer oil outlet

1456986 ZF 0634 801 321
Washer

1475157 ZF 0671 090 374
Paste



1257348 ZF 0730 008 055
washer

1257347 ZF 0730 008 056
washer

1260225 ZF 0730 008 637
washer

1250755 ZF 0734 300 087
oil seal



1249198 ZF 0734 300 093
oil seal























1250754 ZF 0734 300 094
oil seal



















1247957 ZF 0734 300 104
oil seal




| | | |
|---------|---------------------------------------|---|
| 1249468 | ZF 0734 300 185 oil seal |  |
| 1254037 | ZF 0734 300 024 oil seal |  |
| 1475167 | ZF 0734 300 257 Oil seal |  |
| 1475044 | ZF 0734 300 381 Oil seal wheel hub |  |
| 1250737 | ZF 0734 307 272 Gasket |  |
| 1253525 | ZF 0734 307 287 oil seal |  |
| 1250455 | ZF 0734 307 294 Sealing ring |  |
| 1254490 | ZF 0734 309 291 oil seal |  |
| 1256252 | ZF 0734 309 422 oil seal |  |
| 1253980 | ZF 0734 310 102 oil seal |  |











| | | |
|---------|-----------------------------|---|
| 1253270 | ZF 0734 310 104 oil seal |  |
| 1247517 | ZF 0734 310 108 oil seal |  |
| 1249200 | ZF 0734 310 109 oil seal |  |
| 1250019 | ZF 0734 310 110 oil seal |  |
| 1249201 | ZF 0734 310 111 oil seal |  |
| 1248611 | ZF 0734 310 122 oil seal |  |
| 1253959 | ZF 0734 310 124 oil seal |  |
| 1254066 | ZF 0734 310 128 oil seal |  |
| 1253950 | ZF 0734 310 131 oil seal |  |
| 1250166 | ZF 0734 310 165 Oil seal |  |











| | | |
|---------|---|---|
| 1249469 | ZF 073 431 0285 Oil seal wheel hub FKM dph |  |
| 1256993 | ZF 0734 310 298 oil seal |  |
| 1259379 | ZF 0734 310 316 oil seal |  |
| 1254908 | ZF 0734 310 333 oil seal |  |
| 1257444 | ZF 0734 310 342 oil seal |  |
| 1253402 | ZF 0734 310 353 oil seal |  |
| 1253444 | ZF 0734 310 386 oil seal |  |
| 1255023 | ZF 0734 310 387 oil seal |  |
| 1253441 | ZF 0734 310 396 oil seal |  |
| 1255811 | ZF 0734 310 401 oil seal |  |



| | | |
|---------|--------------------------------------|---|
| 1254926 | ZF 0734 310 402 oil seal |  |
| 1254331 | ZF 0734 317 150 seal ring |  |
| 1256634 | ZF 0734 319 052 oil seal |  |
| 1249537 | ZF 0734 319 127 oil seal |  |
| 1253983 | ZF 0734 319 137 oil seal |  |
| 1250742 | ZF 0731 319 330 oil seal |  |
| 1260501 | ZF 0734 319 378 oil seal |  |
| 1253442 | ZF 0734 319 439 oil seal |  |
| 1249775 | ZF 0734 319 459 oil seal |  |
| 1254164 | ZF 0734 319 460 Oil seal oil pump |  |

| | | |
|---------|---|---|
| 1260978 | ZF 0734 319 514 Oil seal differential |  |
| 1249203 | ZF 0734 319 551 oil seal |  |
| 1259783 | ZF 0734 319 559 oil seal |  |
| 1252409 | ZF 0734 319 588 oil seal |  |
| 1259697 | ZF 0734 319 652 Oil seal manual transmission |  |
| 1259378 | ZF 0734 319 706 Oil seal manual transmission |  |
| 1253437 | ZF 0734 319 713 oil seal |  |
| 1260072 | ZF 0734 319 801 Oil seal gearbox |  |
| 1247518 | ZF 0750 110 001 Oil seal wheel hub |  |
| 1257852 | ZF 0750 110 039 Oil seal manual transmission |  |

| | | |
|---------|---|---|
| 1252926 | ZF 0750 110 156 Oil seal wheel hub |  |
| 1247520 | ZF 0750 111 002 Oil seal manual transmission |  |
| 1247521 | ZF 0750 111 004 Oil seal gearbox |  |
| 1257339 | ZF 0750 111 018 Oil seal gearbox |  |
| 1250335 | ZF 0750 111 077 oil seal |  |
| 1250950 | ZF 0750 111 116 oil seal |  |
| 1253443 | ZF 0750 111 149 Oil seal gearbox |  |
| 1250949 | ZF 0750 111 231 oil seal |  |
| 1255417 | ZF 0750 111 328 Oil seal wheel bearing |  |
| 1252512 | ZF 0750 111 341 Oil seal gearbox |  |

| | | |
|---------|--|---|
| 1254766 | ZF 0750 111 402 oil seal |  |
| 1253439 | ZF 0750 111 469 Oil seal gearbox |  |
| 1253440 | ZF 0750 111 476 Oil seal gearbox |  |
| 1250198 | ZF 0750 112 034 part FPM 25x38/49,7x10/14,5 |  |
| 1249091 | ZF 0750 112 066 Sealing ring gearbox |  |
| 1252309 | ZF 0750 112 089 seal gearbox |  |
| 1260063 | ZF 0750 112 169 oil seal |  |
| 1256267 | ZF 0750 112 177 Sealing ring gearbox NBR |  |
| 1260495 | ZF 0750 112 251 seal ring |  |
| 1248491 | ZF 0770 026 073 rubber part |  |











| | | |
|---------|--|---|
| 1248502 | ZF 0770 032 760 seal ring plastic |  |
| 1248501 | ZF 0770 033 322 seal ring ptfe |  |
| 1247876 | ZF 0770 080 244 oil seal |  |
| 1247925 | ZF 0770 080 252 Oil seal steering box |  |
| 1248264 | ZF 0770 080 268 oil seal |  |
| 1257170 | ZF 0770 080 273 oil seal |  |
| 1249793 | ZF 0770 080 286 oil seal |  |
| 1249800 | ZF 0770 080 457 oil seal |  |
| 1249355 | ZF 0770 198 037 oil seal |  |
| 1248307 | ZF 0770 198 103 oil seal |  |









| | | |
|---------|---|---|
| 1250393 | ZF 0770 198 107 oil seal |  |
| 1250753 | ZF 0770 198 130 oil seal |  |
| 1255346 | ZF 0770 198 134 oil seal |  |
| 1259796 | ZF 1238 308 201 Gasket gearbox dph |  |
| 1249765 | ZF 1268 298 903 repair kit 680/690 |  |
| 1256243 | ZF 1268 298 904 Repair kit manual transmission |  |
| 1258210 | ZF 1268 307 170 Gasket gearbox dph |  |
| 1256244 | ZF 1269 298 933 Repair kit manual transmission |  |
| 1255993 | ZF 1290 301 140 Gasket gearbox |  |
| 1258207 | ZF 1290 301 140 Gasket gearbox dph |  |








| | | |
|---------|---|---|
| 1260831 | ZF 1290 301 145 Gasket gearbox |  |
| 1260832 | ZF 1290 301 146 Gasket |  |
| 1471286 | ZF 1295 298 801 Gasket set | |
| 1250285 | ZF 1295 298 915 Gasket set manual transmission |  |
| 1243755 | ZF 1295 298 917 Gasket set manual transmission |  |
| 1250011 | ZF 1295 298 960 Gasket set manual transmission |  |
| 1453765 | ZF 1304298914 Gasket set | |
| 1258213 | ZF 1304 301 305 gasket |  |
| 1260887 | ZF 1307 298 030 / 930 gasket set |  |
| 1259675 | ZF 1307 306 034 Gasket |  |











| | | |
|---------|--|---|
| 1259789 | ZF 1313 301 036 Gasket |  |
| 1259790 | ZF 1313 301 037 Gasket |  |
| 1261109 | ZF 1313 301 038 gasket |  |
| 1259784 | ZF 1313 302 014 Gasket gearbox |  |
| 1259785 | ZF 1313 306 012 Gasket |  |
| 1259788 | ZF 1313 307 002 Gasket |  |
| 1259787 | ZF 1313 307 003 Gasket |  |
| 1471333 | ZF 1313 307 020 Gasket gearbox |  |
| 1250443 | ZF 1315 298 001 Gasket set |  |
| 1258615 | ZF 1315 298 001 Gasket set Paper |  |

| | | |
|---------|---|---|
| 1250453 | ZF 1315 298 002 Repair kit gearbox |  |
| 1250454 | ZF 1315 298 003 Repair kit manual transmission |  |
| 1257860 | ZF 1315 301 095 gasket |  |
| 1259827 | ZF 1315 301 233 Gasket |  |
| 1260984 | ZF 1315 301 234 Gasket |  |
| 1259829 | ZF 1315 303 060 Gasket |  |
| 1260985 | ZF 1315 307 013 Gasket |  |
| 1457028 | ZF 1315 307 242 Gasket |  |
| 1259830 | ZF 1316 301 042 gasket |  |
| 1259705 | ZF 1316 301 053 Gasket |  |

| | | |
|---------|---|---|
| 1258212 | ZF 1324 307 082 Gasket gearbox |  |
| 1250167 | ZF 4139 298 939 Gasket set |  |
| 1244069 | ZF 7430 633 001 Repair kit |  |
| 1243674 | ZF 7673 633 001 Repair kit steering |  |
| 1249411 | ZF 7673 633 005 Gasket set steering dph |  |
| 1250752 | ZF 7824 033 113 oil seal |  |
| 1249571 | ZF 7832 633 005 Gasket set steering |  |
| 1249785 | ZF 7832 633 008 Gasket set steering |  |
| 1249790 | ZF 7836 633 006 Gasket set steering Opel |  |
| 1249798 | ZF 7840 633 003 Gasket set steering Porsche |  |

| | | |
|---------|--|---|
| 1247877 | ZF 7824 033 113 oil seal |  |
| 1249792 | ZF 7847 633 002 Gasket set steering |  |
| 1249797 | ZF 7847 633 004 repairkit steering AUDI | |
| 1249791 | ZF 7847 633 115 Gasket set steering |  |
| 1249796 | ZF 7847 633 116 repairkit steering AUDI | |
| 1248265 | ZF 7852 033 108 oil seal |  |
| 1253886 | ZF 7852 033 110 oil seal |  |
| 1248253 | ZF 7852 633 006 Repair kit steering |  |
| 1252321 | ZF 7852 633 014 Gasket set steering box |  |
| 1249801 | ZF 7852 633 026 Repair kit steering |  |

| | | |
|---------|--|---|
| 1248985 | ZF 7881 633 011 Gasket set steering box |  |
| 1248492 | ZF 8043 033 111 seal ring |  |
| 1249415 | ZF 8043 033 120 gasket |  |
| 1249252 | ZF 8043 633 009 Repair kit steering box |  |
| 1254336 | ZF 8043 633 017 Repair kit steering box |  |
| 1249412 | ZF 8043 633 025 Repair kit steering box |  |
| 1257210 | ZF 8044 698 068 repair kit Scania 112 |  |
| 1248498 | ZF 8045 033 128 Sealing ring |  |
| 1248508 | ZF 8045 033 130 Gasket |  |
| 1248509 | ZF 8045 033 143 Sealing ring |  |

| | | |
|---------|--|---|
| 1248335 | ZF 8045 633 001 Repair kit steering box |  |
| 1244291 | ZF 8045 633 005 Repair kit steering box |  |
| 1249786 | ZF 8051 633 013 Repair kit steering |  |
| 1249788 | ZF 8052 633 028 Repair kit steering |  |
| 1249789 | ZF 8052 633 034 Repair kit steering box |  |
| 1253197 | ZF 8065 633 017 Repair kit hydraulic pump |  |
| 1253195 | ZF 8065 633 025 Gasket set steering box |  |
| 1253196 | ZF 8065 633 035 Repair kit |  |
| 1248493 | ZF 8066 033 111 Gasket |  |
| 1254341 | ZF 8090 633 010 Repair kit steering box |  |

1254342 ZF 8090 633 016
Repair kit steering box



1254344 ZF 8097 633 005
Repair kit steering box




1253194 ZF 8098 633 003
Repair kit steering box



1255785 ZF 8098 633 019
Repair kit steering box



1459801 ZF 8098 633 042
Gasket set gearbox



1459740 ZF 8098 633 083
Repair kit



1462040 ZF 9S1110
Gasket gearbox
metal

